PIFCO

..it's a way of life

MAINTENANCE

- 1. Always disconnect the appliance from the mains by switching it off and removing the plug from the power outlet before cleaning.
- 2. Do not allow water to penetrate the motor during cleaning.
- 3. It is advisable to use a neutral detergent and a soft cloth and to rub dry.

 Do not use solvents, acidic detergents, petrol or alcohol etc. to clean the plastic components, as these could be deformed or damaged.
- 4. Pack the fan in the original box and place it in a dry, well-ventilated place when it is not to be used for a long period of time.

STORAGE

- Store the tower after it has cooled down.
- When not in use, store the Solid Hot Plate in a safe, dry place, out of reach of children.



Disposal of Unit

Disposal instructions for Pifco items in accordance with the WEEE directive. Appliances bearing the symbol shown here may not be disposed of in domestic rubbish. You are required to dispose of old electrical and electronic appliances like this separately. Please visit www.recyclemore.co.uk, or www.recylcenow.co.uk for access to information about the recycling of electrical items. The WEEE directive, introduced in August 2006, states that all electrical items must be recycled, rather than taken to landfill. Please arrange to take this appliance to your local Civic Amenity site for recycling, once it has reached the end of its life.

Imported & Distributed throughout the U.K. By PFD. ST4 2NL www.pifco-products.co.uk



Instruction Manual



Tower Fan
74CM (29")

Products may vary from those illustrated

PC006

PC006_IM.indd 2-3 18/01/2012 16:58:33

Technical Support

If you require technical support or in the unlikely event that your purchase is faulty please telephone our Helpline for immediate assistance.

01733404702

Parts Identification

- I- Front guard
- 2- Front cover
- 3- Guard
- 4- Operating switches
- 5-Timer
- 6- Oscillation switch
- 7- Rear cover
- 8- Rear guard
- 9- Power Cord (Not Shown)
- 10- Base (Comes in 2 peices)



Technical Data

Specification
Model No.
PC006
Rated Voltage & Frequency
220V-240V ~50Hz
Power consumption
20W




What is in the Box

I.Ix Appliance 2.2x Sections of the Base Fixings for the Base

Base Assembly

- I. Pass the cord (9) through the base (10)
- 2. Insert the front cover (2) in the base





Important Safey Information

- I. Remove the packaging and make sure that the appliance is intact. If in doubt, do not use it and contact qualified personnel only.
- 2. Packaging materials (plastic bags, polystyrene, staples etc.) must be kept out of the reach of children as they could be hazardous.
- 3. Caution:The appliance is not intended to be used by children or the infirm, unless they are supervised or given instructions on how to use the appliance by a person responsible for their safety.
- 4. Before connecting the appliance, check that the appliance rating corresponds to the mains rating.
- 5. This appliance must only be used for the purpose for which it has been manufactured, i.e. as a tower fan and for household use only. The manufacturer is not responsible for any damage caused by improper or incorrect use.
- 6. Before cleaning or carrying out maintenance on the appliance, disconnect it from the electrical mains by removing the plug from the electrical outlet or by switching off the system switch.
- 7. If the appliance is faulty and/or operating incorrectly, switch it off without tampering with it. If the above is disregarded, the safety of the appliance may be compromised.
- 8. Switch off the appliance and remove the plug from the electrical outlet or switch off the system switch when not in use.
- 9.The use of any electrical appliance calls for the awareness of some basic rules, such as:

Do not touch the appliance with wet or damp hands or feet Do not leave the appliance exposed to atmospheric agents

- 10. Max. Ambient temperature 40°C.
- 11. Do not use the appliance in the presence of potentially flammable or explosive liquids or gases.
- 12. Warning Do not use this product in conjunction with an external timer as this may compromise your safety

Choose one of the following 4 butons on the control panel to select the required fan speed

 $0 = stop \ I = minimum \ speed \ 2 = medium \ speed \ 3 = maximum \ speed \ OSCILLATION$

Press button 6 and the fan begins to oscillate.

TIMER

The timer can be set up to 120 minutes.



PC006_IM.indd 4-5 18/01/2012 16:58:34